




TOP AND CONSOLE PARTS

For Models: LGR4634EW0, LGR4634EQ0, LGR4634EZ0
(White)(Designer White)(Designer Almond)

GAS DRYER



WIRING HARNESS PARTS	
15	
17	
24	
25	
75	
18	
5	
9	

1	3397545	Panel, Rear Console
3	693995	Screw, Hex Head
4		Cap, End (L.H.)
	3358531	LGR4634EW0
	3358528	LGR4634EQ0
	3358529	LGR4634EZ0
5	353425	Connector (Door Switch)
6	688805	Clip
7		Cap, End (R.H.)
	3358516	LGR4634EW0
	3358513	LGR4634EQ0
	3358514	LGR4634EZ0
8	357213	Nut, Push-In (2)
9	3395683	Housing, Connector (Motor)
10	339392	Screen, Lint
11		Cover, Lint Screen
	688150	White
	689310	Almond
12	339229	Hinge, R.H.
	339230	Hinge, L.H.
13	688983	Screw, 8-18 x 5/8
14	388326	Screw, Console
15	3397269	Connector (Timer)
16		Top
	3396022	White
	3396023	Almond
17	3394427	Clip, Harness
18	94614	Terminal
21	3393934	Timer Assembly, 60 Hz.
23	3405111	Harness, Wiring
24	3403499	Connector, 2-Position (Gas Valve)
25	3403498	Connector, 3-Position (Gas Valve)
29	3390646	Screw, 8-18 x 5/16
39	3395382	Switch, Push-To-Start
48		Timer Knob & Dial
	3396145	LGR4634EW0
	3396146	LGR4634EQ0
	3396149	LGR4634EZ0
53	3396293	Bracket, Control
54		Panel, Control
	3399047	LGR4634EW0
	3399048	LGR4634EQ0
	3399049	LGR4634EZ0
72	690853	Wire, Ground
75	717252	Receptacle, Latching (2-Way) (Uses Terminal 94614)
81		Knob, Push-To-Start
	3396160	LGR4634EW0
	3396161	LGR4634EQ0
	3396164	LGR4634EZ0

LITERATURE AND OPTIONAL PARTS

LITERATURE PARTS

LIT3401094	Use & Care Guide
LIT3395337	Instructions, Installation
LIT3405722	Instructions, Door Reversing
LIT3401728	Label, Wiring Diagram

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH-UP (1/2oz.)

72017	White
72107	Almond

PAINT, PRESSURIZED SPRAY (13 oz.)

350930	White
350956	Almond
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)


Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

LIT677818	Dryer
-----------	-------

CABINET PARTS

For Models: LGR4634EW0, LGR4634EQ0, LGR4634EZ0
(White)(Designer White)(Designer Almond)




1	697776	Screw, 10-16 x 1/2
2	343641	Screw, 10-16 x 1/2
3		Plug, Strike Hole
	3403630	White
	3403631	Almond
4		Plug, Hinge Hole (4)
	3404413	White
	3404414	Almond
5	3396795	Cover, Block
6		Plug, Front Panel
	3394975	White
	3394976	Almond
7	3396807	Panel, Rear
8	342055	Screw, 8-18 x 1/2
9	691581	Clip, Door Switch
10	347207	Switch, Door
11	98129	Screw, 6-20 x 7/8 (2)
12	3388580	Cable Assembly
13	238614	Bumper
14	3405104	Harness, Wiring (Door Switch)
15	3394083	Clip, Front Panel
16	3392100	Foot, Dryer
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)
18		Cabinet (Includes Illus. Nos. 5, 7, 15, 16 & 57)
	3399580	White
	3399581	Almond
19	98234	Clip, Ground (2)
20	690363	Lock, Front Top (2)
21		Front Panel Assembly
	3403574	White
	3403575	Almond
23	685203	Clip, Felt Pad
24	3389441	Catch, Door
25	693995	Screw, Hex Head
28	3405514	Hinge & Pin Assembly
32	694091	Screw
33	3403431	Strike, Door
35	3403371	Door, Rear
36		Door, Front
	3403361	White
	3403362	Almond
37		Handle, Door
	3405184	White
	3405185	Almond
38	349464	Seal & Bearing Assembly
42	3390733	Seal, Door
45	344020	Cord, Power
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	660996	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16-18 x 3/4
59	3401143	Pulley, 60 Hz.
62	3395652	Motor, 60 Hz.
63	660658	Clamp, Motor
64	3404162	Clamp, Motor (W/Shield)

67 3401771 Burner Assembly, 60 Hz. (Refer To Burner Assembly Parts Page
For Further Breakdown)
68 341029 Clamp, Pipe
69 694572 Kit, Conversion (Type 1, 2 & 3 To Type 4)
85 3401775 Valve, Gas 60 Hz. (Complete)
86 686590 Ignitor
87 3393909 Screw & Washer
88 694539 Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
89 694540 Coil, 60 Hz. (2 Terminal) (Main)
90 694421 Screw, Bracket Mounting (8-32 x 1/2)
91 694538 Bracket, Coil
93 694424 Leak Limiter
94 694423 Screw, Regulator Adjustment
95 694422 Spring, Regulator
97 239822 Plug, Pipe

3401771 BURNER ASSEMBLY

For Models: LGR4634EW0, LGR4634EQ0, LGR4634EZ0
(White)(Designer White)(Designer Almond)

USE WITH TYPE 1 - NATURAL, TYPE 2 - MIXED, TYPE 3 - MANUFACTURED
AND TYPE 4 - LIQUEFIED PROPANE AND BUTANE GASES




1	3401771	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10-16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8-18 x 3/8 (2)
9		Orifice, Burner
	234826	Type 1
	15775	Type 2
	15419	Type 3
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	3401775	Valve, 60 Hz.
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
21	233273	Pipe, Gas Supply
22	345062	Valve & Union, Shut-Off
23	3393767	Pipe, Tail
24	233076	Nut, Compression
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572	Conversion Kit (Type 1, 2 & 3) to Type (4) L.P.G.
--------	---

BULKHEAD PARTS

For Models: LGR4634EW0, LGR4634EQ0, LGR4634EZ0
(White)(Designer White)(Designer Almond)



1	694283	Lint Chute Assembly
2	343641	Screw, 10-16 x 1/2
3	3406022	Bracket, Bulkhead
4	3388703	Washer, Support
5	90767	Screw, 8A x 3/8
6	3392519	Fuse, Thermal
7	347139	Seal, Lint Chute
8	3387134	Thermostat, Internal-Bias
9	339554	Screw
10	694089	Wheel, Blower
11	3405016	Housing, Blower
12	3398161	Clip
13	3400800	Screw, 8-18 x 3/4
14	685458	Box, Heater
15	3403140	Thermostat, 205~F (96.1~C)
16	337445	Support, Heater Box (2)
17	337450	Collar, Funnel
18	347389	Funnel, Burner
24	696302	Shield, Exhaust
26	3392247	Pad, Blower Housing
27	3392123	Seal, Blower Shaft
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3397264	Bulkhead
49	338906	Sensor, Radiant
62	3394509	Ring, Bearing
63	97787	Screw, 11-16 x 7/8
66	337449	Seal, Rear Drum
67	3396777	Drum Assembly
68	342847	Baffle, Drum
69	348945	Bracket, Support
70	90296	Clip
73	339956	Seal